



### Remote Operation


Single Channel



Multi Channel




BACK



1




Power on shutter  
Listen for long  
BEEP



**\*Complete programming  
within 4 seconds of beep**

### When Motor is on Outside Left


**2** Press the Program Button on back 2 times  
**3** Press up button on remote 1 time  
COMPLETE Now set limits



**\*** If programming is incorrect for up/down, just repeat steps 2-3 for correct side


### When Motor is on Outside Right

**2** Press the Program Button on back 2 times  
**3** Press down button on remote 1 time  
COMPLETE Now set limits



**\*** If programming is incorrect for up/down, just repeat steps 2-3 for correct side


### Factory Limit Setting Instructions



### Additional Programming Instructions

#### Jumping programming

**1** On already programmed remote or channel press program Button 2 times  
**2** On a new remote or new channel press program button 2 times  
COMPLETE



#### Factory Reset programming

**1** Press P2 1 time  
**2** Press STOP 1 time  
**3** Press P2 1 time  
Reset Complete  
Listen for 3 BEEP confirmation

